

Conexiones de Instrumentación

Codo Unión

D.E. del Tubo	Intercambios	Acero Inoxidable 316 # de Parte
1/4"	400-9	4-DELU-4
3/8"	600-9	6-DELU-6
1/2"	810-9	8-DELU-8
5/8"	1010-9	10-DELU-10
3/4"	1210-9	12-DELU-12
1"	1610-9	16-DELU-16



E

Tee de Ramificación Macho

D.E. del Tubo	Macho NPT	Intercambios	Acero Inoxidable 316 # de Parte
1/8"	1/8"-27	200-3TTM	2-DTTM-2
1/4"	1/4"-18	400-3-4TMT	4-DTTM-4
1/2"	3/8"	810-3TTM	8-DTTM-6
1/2"	1/2"	810-3-8TTM	8-DTTM-8
3/4"	1/2"	1210-3-8TTM	12-DTTM-8
3/4"	3/4"	1210-3TTM	12-DTTM-12
1"	3/4"	1610-3-12TTM	16-DTTM-12
1"	1"	1610-3-16TTM	16-DTTM-16



Tee de Ramificación Hembra

D.E. del Tubo	Hembra NPT	Intercambios	Acero Inoxidable 316 # de Parte
1/4"	1/4"-18	400-3-4TTF	4-DTTF-4



Tee Unión

D.E. del Tubo	Intercambios	Acero Inoxidable 316 # de Parte
1/4"	400-3	4-DTTT-4
3/8"	600-3	6-DTTT-6
1/2"	810-3	8-DTTT-8
5/8"	1010-3	10-DTTT-10
3/4" x 3/8"	1210-3-12-6	12-DTTT-6
3/4" x 1/2"	1210-3-12-8	12-DTTT-8
3/4"	1210-3	12-DTTT-12
1" x 3/4"	1610-3-12-16	16-DTTT-12
1"	1610-3	16-DTTT-16



Tee de Flujo Macho

D.E. del Tubo	Macho NPT	Intercambios	Acero Inoxidable 316 # de Parte
1/8"	1/8"-27	200-3TMT	2-DTMT-2
1/4"	1/4"-18	400-3-4TMT	4-DTMT-4
3/8"	1/4"-18	600-3TMT	6-DTMT-4
1/2"	3/8"	810-3TMT	8-DTMT-6
1/2"	1/2"	810-3-8TMT	8-DTMT-8
3/4"	3/4"	1210-3TMT	12-DTMT-12
1"	3/4"	1610-3-12TMT	16-DTMT-12
1"	1"	1610-3-16TMT	16-DTMT-16

